

PAX S300

Quick Reference Guide

SETUP

Your terminal is preprogrammed and ready for use as soon as it is connected to your software or POS system! Once that part is completed, follow these steps:

- 1) Plug into Ethernet
- 2) Plug into wall
- 3) Turn on

TERMINAL PASSWORD: Default password is the number 1

SUPPORT

PHONE: 800-675-6573

EMAIL: service@bluefin.com

HOURS:

Monday- Friday 7 AM – 6 PM Central Saturday 8 AM – 4:30 PM Central



PROCESSING

	Swiped transaction	 Initiate transaction in software or POS, terminal will ask for card to be swiped Swipe card
SALE	Keyed transaction	 Initiate transaction in software or POS, terminal will ask for card to be swiped Enter card number, expiration date, and additional info as prompted (varies)
		depending on programming).
		NOTE: if it asks for the address you only need to enter the street number
	Void a transaction	1) Initiate void in software or POS, terminal will ask for transaction number
Щ	Prevents sale from settling,	2) Enter transaction number
SALE	use in place of refund if	3) Press the green Enter button on the keypad
S)	transaction has not batched	NOTE: These steps can vary slightly depending on software-specific
>	out	programming
	Refund a transaction	1) Initiate return in software or POS
Z	Only refund transactions that	2) Enter amount in terminal
	were not run the same day	3) Swipe or key card
RETURN		NOTE: These steps can vary slightly depending on software-specific programming

АПТН	Authorization Authorizations do not settle unless manually captured.	 Initiate transaction in software or POS, terminal will ask for card to be swiped Swipe or key card
FORCED	Force sale Manually capture an existing authorization.	 Initiate transaction in software or POS, terminal will ask for card to be swiped Swipe or key card Enter auth code into terminal Press the green Enter button on the keypad
ватсн	Closing a batch NOTE: Batches are closed within Bluefin's PayConex backend system, these instructions are to clear transactions out of the terminal	 Press "Menu" on the screen Enter "1" for password (unless you've changed it) Press the green Enter button on the keypad Press "4" for "Host Settings" Enter "1" for password (unless you've changed it) Press the green Enter button on the keypad Press the down arrow on the screen Press "1" for "Batch Close"

SETTINGS

	Make certain	1) Press "Menu" on the screen
	transaction types	2) Enter "1" for password (unless you've changed it)
	password protected	3) Press the green Enter button on the keypad
		4) Press 2 for "Merchant Settings"
		5) Press 1 for "Authorization"
		6) Enter "1" for password (unless you've changed it)
		7) Press the green Enter button on the keypad
		8) Press 1 for "Transaction Types"
		9) Choose the transaction type you want to make password-protected; on the next
		screen you will specify further
>		10) Choose whether returns, sales, etc. should be password protected
		11) Press 3 for "Pswd Protected"
2		
ಕ	Enabling or disabling	1) Press "Menu" on the screen
Ш (O	address verification	2) Enter "1" for password (unless you've changed it)
SECURITY	address verification (AVS) settings	3) Press the green Enter button on the keypad
SE		3) Press the green Enter button on the keypad4) Press the down arrow on the screen
S		3) Press the green Enter button on the keypad4) Press the down arrow on the screen5) Press "1" for "System Settings"
SE		 3) Press the green Enter button on the keypad 4) Press the down arrow on the screen 5) Press "1" for "System Settings" 6) Press "3" for "Working Mode"
SE		 3) Press the green Enter button on the keypad 4) Press the down arrow on the screen 5) Press "1" for "System Settings" 6) Press "3" for "Working Mode" 7) Enter "1" for password (unless you've changed it)
S		 3) Press the green Enter button on the keypad 4) Press the down arrow on the screen 5) Press "1" for "System Settings" 6) Press "3" for "Working Mode" 7) Enter "1" for password (unless you've changed it) 8) Press the green Enter button on the keypad
S		 3) Press the green Enter button on the keypad 4) Press the down arrow on the screen 5) Press "1" for "System Settings" 6) Press "3" for "Working Mode" 7) Enter "1" for password (unless you've changed it) 8) Press the green Enter button on the keypad 9) Press "2" for "Fraud Control"
S		 3) Press the green Enter button on the keypad 4) Press the down arrow on the screen 5) Press "1" for "System Settings" 6) Press "3" for "Working Mode" 7) Enter "1" for password (unless you've changed it) 8) Press the green Enter button on the keypad 9) Press "2" for "Fraud Control" 10) Select the option you want to change – most likely "3" for "AVS On CardNotPrsnt"
S		 3) Press the green Enter button on the keypad 4) Press the down arrow on the screen 5) Press "1" for "System Settings" 6) Press "3" for "Working Mode" 7) Enter "1" for password (unless you've changed it) 8) Press the green Enter button on the keypad 9) Press "2" for "Fraud Control" 10) Select the option you want to change – most likely "3" for "AVS On CardNotPrsnt" 11) On the next screen select the card types you want to include – most likely 1 for "All"
Ŋ		 3) Press the green Enter button on the keypad 4) Press the down arrow on the screen 5) Press "1" for "System Settings" 6) Press "3" for "Working Mode" 7) Enter "1" for password (unless you've changed it) 8) Press the green Enter button on the keypad 9) Press "2" for "Fraud Control" 10) Select the option you want to change – most likely "3" for "AVS On CardNotPrsnt"

	Disable or enable	1) Press "Menu" on the screen
	the beeping noise	2) Enter "1" for password (unless you've changed it)
		3) Press the green Enter button on the keypad
		4) Press 3 for "Operations Settings"
		5) Press 1 for "Buzzer Setup"
		6) Select the buzzer you want to disable
		7) Follow the prompt to turn it off or on
	Put in demo mode	1) Press "Menu" on the screen
	or remove from	2) Enter "1" for password (unless you've changed it)
	demo mode for	3) Press the green Enter button on the keypad
	training or testing	4) Press 3 for "Operation Settings"
		5) Press 2 for "Operation Mode"
		6) Enter "1" for password (unless you've changed it)
		7) Press the green Enter button on the keypad
		8) Press "1" to put in normal mode or "2" to put in demo mode
		9) On the next screen when it says "Are you sure?" press 1 for "Yes"
		3) On the next screen when it says. Are you sure: press 1 to Tes
	Change logo on	Create a version of your logo that is exactly 240x320 pixels
	image screen	2) Email to service@bluefin.com and specify that you want it added to the programming
	inage sereen	for your PAX S300 terminal
		3) When you receive confirmation that it has changed, turn terminal off and back on
₹		NOTE: If you do not know how to change the image size, just send us your logo and we will
GENERA		crop it for you
5	Changing the time	1) Press "Menu" on the screen
	or date on the	2) Enter "1" for password (unless you've changed it)
	device	3) Press the green Enter button on the keypad
	device	4) Press the down arrow on the screen
		5) Press "1" for "System Settings"
		6) Press "1" for "Date/Time Setup"
		•
		7) If the date is already correct, press the green button to bypass the screen, if it is
		incorrect, press the "X" button on the keypad and then enter the date in the format
		of DDMMYYYY
		8) Press the green Enter button on the keypad
		9) The time screen will come up next, if it is already correct press the green button to
		bypass the screen, if it is incorrect, press the "X" button on the keypad and then enter
		the time in the form of HHMMSS
	Character 157	A) December 21 and 1 and 2 and
	Changing if/when	1) Press "Menu" on the screen
	backlight turns	2) Enter "1" for password (unless you've changed it)
	on/off	3) Press the green Enter button on the keypad
		4) Press "3" for "Operation Settings"
		5) Press "3" for "Screen Backlight"
		6) Press "1" for it to always be off, "2" for it to be on but turn off after 60 seconds, or "3"
		•
		to always be on